



# **A33 Nand Flash Controller Specification**

**Revision 1.0**

**Feb.28,2014**

# DECLARATION

THIS DOCUMENTATION IS THE ORIGINAL WORK AND COPYRIGHTED PROPERTY OF ALLWINNER TECHNOLOGY (“ALLWINNER”). REPRODUCTION IN WHOLE OR IN PART MUST OBTAIN THE WRITTEN APPROVAL OF ALLWINNER AND GIVE CLEAR ACKNOWLEDGEMENT TO THE COPYRIGHT OWNER.

THE PURCHASED PRODUCTS, SERVICES AND FEATURES ARE STIPULATED BY THE CONTRACT MADE BETWEEN ALLWINNER AND THE CUSTOMER. PLEASE READ THE TERMS AND CONDITIONS OF THE CONTRACT AND RELEVANT INSTRUCTIONS CAREFULLY BEFORE USING, AND FOLLOW THE INSTRUCTIONS IN THIS DOCUMENTATION STRICTLY. ALLWINNER ASSUMES NO RESPONSIBILITY FOR THE CONSEQUENCES OF IMPROPER USE(INCLUDING BUT NOT LIMITED TO OVERVOLTAGE, OVERCLOCK, OR EXCESSIVE TEMPERATURE).

THE INFORMATION FURNISHED BY ALLWINNER IS PROVIDED JUST AS A REFERENCE OR TYPICAL APPLICATIONS, ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS DOCUMENT DO NOT CONSTITUTE A WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. ALLWINNER RESERVES THE RIGHT TO MAKE CHANGES IN CIRCUIT DESIGN AND/OR SPECIFICATIONS AT ANY TIME WITHOUT NOTICE.

NOR FOR ANY INFRINGEMENTS OF PATENTS OR OTHER RIGHTS OF THE THIRD PARTIES WHICH MAY RESULT FROM ITS USE. NO LICENSE IS GRANTED BY IMPLICATION OR OTHERWISE UNDER ANY PATENT OR PATENT RIGHTS OF ALLWINNER.

THIRD PARTY LICENCES MAY BE REQUIRED TO IMPLEMENT THE SOLUTION/PRODUCT. CUSTOMERS SHALL BE SOLELY RESPONSIBLE TO OBTAIN ALL APPROPRIATELY REQUIRED THIRD PARTY LICENCES. ALLWINNER SHALL NOT BE LIABLE FOR ANY LICENCE FEE OR ROYALTY DUE IN RESPECT OF ANY REQUIRED THIRD PARTY LICENCE. ALLWINNER SHALL HAVE NO WARRANTY, INDEMNITY OR OTHER OBLIGATIONS WITH RESPECT TO MATTERS COVERED UNDER ANY REQUIRED THIRD PARTY LICENCE.

## Revision History

Version	Date	Author	Reviewer	Description
1.0	Feb.28, 2014			



# Table of Contents

DECLARATION .....	2
Revision History .....	3
1. NAND Flash Controller.....	5
1.1. NDFC Overview.....	5
1.2. NDFC Timing Diagram.....	6
1.3. NDFC Register List.....	11
1.4. NDFC Register Description.....	12
1.4.1. NDFC Control Register .....	12
1.4.2. NDFC Status Register.....	13
1.4.3. NDFC Interrupt and DMA Enable Register.....	15
1.4.4. NDFC Timing Control Register.....	15
1.4.5. NDFC Timing Configure Register.....	16
1.4.6. NDFC Address Low Word Register.....	17
1.4.7. NDFC Address High Word Register.....	18
1.4.8. NDFC Data Block Number Register .....	18
1.4.9. NDFC Data Counter Register .....	19
1.4.10. NDFC Command IO Register.....	19
1.4.11. NDFC Command Set Register 0.....	21
1.4.12. NDFC Command Set Register 1.....	21
1.4.13. NDFC IO Data Register.....	21
1.4.14. NDFC ECC Control Register .....	22
1.4.15. NDFC ECC Status Register.....	23
1.4.16. NDFC Enhanced Feature Register.....	23
1.4.17. NDFC Error Counter Register 0.....	24
1.4.18. NDFC Error Counter Register 1 .....	24
1.4.19. NDFC Error Counter Register 2 .....	24
1.4.20. NDFC Error Counter Register 3 .....	25
1.4.21. NDFC User Data Register [n].....	25
1.4.22. NDFC EFNAND STATUS Register.....	25
1.4.23. NDFC Spare Area Register.....	26
1.4.24. NDFC Pattern ID Register.....	26
1.4.25. NDFC Read Data Status Register.....	26
1.4.26. NDFC Read Data Status Register 0.....	27
1.4.27. NDFC Read Data Status Register 1 .....	27
1.4.28. NDFC MBUS DMA Address Register .....	27
1.4.29. NDFC MBUS DMA Byte Counter Register.....	27
1.5. NDFC Operation Diagram.....	28

# 1. NAND Flash Controller

## 1.1. NDFC Overview

The NDFC is the NAND Flash Controller which supports all NAND/MLC flash memory available in the market. New type flash can be supported by software re-configuration.

The On-the-fly error correction code (ECC) is built-in NDFC for enhancing reliability. BCH is implemented and it can detect and correct up to 64 bits error per 512 or 1024 bytes data. The on chip ECC and parity checking circuitry of NDFC frees CPU for other tasks. The ECC function can be disabled by software.

The data can be transferred by DMA or by CPU memory-mapped IO method. The NDFC provides automatic timing control for reading or writing external Flash. The NDFC maintains the proper relativity for CLE, CE# and ALE control signal lines. Three kinds of modes are supported for serial read access. The conventional serial access is mode 0 and mode 1 is for EDO type and mode 2 for extension EDO type. NDFC can monitor the status of R/B# signal line.

Block management and wear leveling management are implemented in software.

The NDFC includes the following features:

- Supports all SLC/MLC/TLC flash and EF-NAND memory available in the market
- Software configure seed for randomize engine
- Software configure method for adaptability to a variety of system and memory types
- Supports 8-bit data bus width
- Supports 1024, 2048, 4096, 8192, 16384 bytes size per page
- Supports 3.3V voltage supply Flash
- Supports conventional and EDO serial access method for serial reading Flash
- On-the-fly BCH error correction code can correct up to 64 bits per 512 or 1024 bytes
- Corrected Error bits number information report
- ECC automatic disable function for all 0xff data
- NDFC status information is reported by its' registers and interrupt is supported
- One Command FIFO
- External DMA is supported for transferring data
- Two 256x32-bit RAM for Pipeline procession
- Supports SDR, DDR and Toggle NAND
- Supports self –debug for NDFC debug

The system block diagram of the NDFC is shown as follows.




Figure 1. NDFC Block Diagram

## 1.2. NDFC Timing Diagram

Typically, there are two kinds of serial access method. One method is conventional method which fetching data at the rise edge of NDFC\_RE# signal line. Another one is EDO type which fetching data at the next fall edge of NDFC\_RE# signal line.

Conventional Serial Access after Read Cycle (SAM0):




Figure 2. Conventional Serial Access Cycle Diagram (SAM0)

EDO type Serial Access after Read Cycle (SAM1):




Figure 3. EDO type Serial Access after Read Cycle (SAM1)




Figure 4. Extending EDO type Serial Access Mode (SAM2)




Figure 5. Command Latch Cycle




Figure 6. Address Latch Cycle




Figure 7. Write Data to Flash Cycle




Figure 8. Waiting R/B# ready Diagram




Figure 9. WE# high to RE# low Timing Diagram




Figure 10. RE# high to WE# low Timing Diagram




Figure 11. Address to Data Loading Timing Diagram

Timing cycle list:

ID	Parameter	Timing	Notes
T1	NDFC_CLE setup time	2T	
T2	NDFC_CLE hold time	2T	
T3	NDFC_CE setup time	2T	
T4	NDFC_CE hold time	2T	
T5	NDFC_WE# pulse width	T	
T6	NDFC_WE# hold time	T	
T7	NDFC_ALE setup time	2T	
T8	Data setup time	T	
T9	Data hold time	T	
T10	Ready to NDFC_RE# low	3T	
T11	NDFC_ALE hold time	2T	
T12	NDFC_RE# pulse width	T	
T13	NDFC_RE# hold time	T	
T14	Read cycle time	2T	
T15	Write cycle time	2T	
T16	NDFC_WE# high to R/B# busy	tWB	Specified by timing configure register (NDFC_TIMING_CFG)
T17	NDFC_WE# high to NDFC_RE# low	tWHR	Specified by timing configure register (NDFC_TIMING_CFG)
T18	NDFC_RE# high to NDFC_WE# low	tRHW	Specified by timing configure register (NDFC_TIMING_CFG)
T19	Address to Data Loading time	tADL	Specified by timing configure register (NDFC_TIMING_CFG)

Notes: T is the cycle of internal clock.

### 1.3. NDFC Register List

Module Name	Base Address
NDFC	0x01C03000

Register Name	Offset	Description
NDFC_CTL	0x00	NDFC Configure and Control
NDFC_ST	0x04	NDFC Status Information
NDFC_INT	0x08	NDFC Interrupt Control
NDFC_TIMING_CTL	0x0C	NDFC Timing Control
NDFC_TIMING_CFG	0x10	NDFC Timing Configure
NDFC_ADDR_LOW	0x14	NDFC Low Word Address
NDFC_ADDR_HIGH	0x18	NDFC High Word Address
NDFC_BLOCK_NUM	0x1C	NDFC Data Block Number
NDFC_CNT	0x20	NDFC Data Counter for Data Transfer
NDFC_CMD	0x24	Set up NDFC Commands
NDFC_RCMD_SET	0x28	Read Command Set for Vendor's NAND Memory
NDFC_WCMD_SET	0x2C	Write Command Set for Vendor's NAND Memory
NDFC_ECC_CTL	0x34	ECC Configure and Control
NDFC_ECC_ST	0x38	ECC Status and Operation Information
NDFC_EFR	0x3C	Enhanced Feature Register
NDFC_ERR_CNT0	0x40	Corrected Error Bit Counter0
NDFC_ERR_CNT1	0x44	Corrected Error Bit Counter1
NDFC_USER_DATA <sub>n</sub>	0x50+4*n	User Data Field Register n (n from 0 to 15)
NDFC_EFNAND_STA	0x90	EFNAND Status Register
NDFC_SPARE_AREA	0xA0	Spare Area Configure Register
NDFC_PAT_ID	0xA4	Pattern ID Register
NDFC_RDATA_STA_CTL	0xA8	Read Data Status Control Register
NDFC_RDATA_STA_0	0xAC	Read Data Status Register0
NDFC_RDATA_STA_1	0xB0	Read Data Status Register1
NDFC_MDMA_ADDR	0xC0	MBUS DMA Address Register
NDFC_MDMA_CNT	0xC4	MBUS DMA Data Counter Register
NDFC_IO_DATA	0x300	Data Input/Output Port
RAM0_BASE	0x400	1024 Bytes RAM0 Base
RAM1_BASE	0x800	1024 Bytes RAM1 Base

## 1.4. NDFC Register Description

### 1.4.1. NDFC Control Register

Offset: 0x00			Register Name: NDFC_CTL Default Value: 0x0000_0000
Bit	Read/Write	Default	Description
31:28	/	/	/
27:24	R/W	0	NDFC_CE_SEL Chip Select for 8 NAND Flash Chips 0 -7: NDFC Chip Select Signal 0-7 is selected 8-15: NDFC CS[7:0] not selected. GPIO pins can be used for CS. NDFC can support up to 16 CS.
23:22	/	/	/
21	R/W	0	NDFC_DDR_RM DDR Repeat Data Mode 0: Lower byte 1: Higher byte
20	R/W	0	NDFC_DDR_REN DDR Repeat Enable 0: Disable 1: Enable
19:18	R/W	0	NF_TYPE NAND Flash Type 00: Normal SDR NAND 01: Reserved 10: ONFI DDR NAND 11: Toggle DDR NAND
17	R/W	0	NDFC_CLE_POL NDFC Command Latch Enable (CLE) Signal Polarity Select 0: High active 1: Low active
16	R/W	0	NDFC_ALE_POL NDFC Address Latch Enable (ALE) Signal Polarity Select 0: High active 1: Low active
15	R/W	0	NDFC_DMA_TYPE 0: Dedicated DMA 1: Normal DMA
14	R/W	0	NDFC_RAM_METHOD Access internal RAM method 0: Access internal RAM by AHB bus

			1: Access internal RAM by DMA bus
13:12	/	/	/
11:8	R/W	0	<p>NDFC_PAGE_SIZE</p> <p>0x0: 1024 bytes</p> <p>0x1: 2048 bytes</p> <p>0x2: 4096 bytes</p> <p>0x3: 8192 bytes</p> <p>0x4: 16384 bytes</p> <p>Notes: The page size is for main field data.</p>
7	/	/	/
6	R/W	0	<p>NDFC_CE_ACT</p> <p>Chip Select Signal CE# Control during NAND Operation</p> <p>0: De-active Chip Select Signal NDFC_CE# during data loading, serial access and other no operation stage for power consumption. NDFC automatic control Chip Select Signals.</p> <p>1: Chip select signal NDFC_CE# is always active after NDFC is enabled.</p>
5	/	/	/
4:3	R/W	0	<p>NDFC_RB_SEL</p> <p>NDFC External R/B Signal Select</p> <p>The value 0-3 selects the external R/B signal. The same R/B signal can be used for multiple chip select flash.</p>
2	R/W	0	<p>NDFC_BUS_WIDTH</p> <p>0: 8-bit bus</p> <p>1: 16-bit bus</p>
1	R/W	0	<p>NDFC_RESET</p> <p>NDFC Reset</p> <p>Write 1 to reset NDFC and clear to 0 after reset.</p>
0	R/W	0	<p>NDFC_EN</p> <p>NDFC Enable Control</p> <p>0: Disable NDFC</p> <p>1: Enable NDFC</p>

### 1.4.2. NDFC Status Register

<b>Offset: 0x04</b>			<b>Register Name: NDFC_ST</b>
			<b>Default Value: 0x0000_0000</b>
Bit	Read/Write	Default	Description
31:14	/	/	/
13	R	/	<p>NDFC_RDATA_STA_0</p> <p>0: The number of bit 1 during current read operation is greater than threshold value.</p> <p>1: The number of bit 1 during current read operation is less than or equal</p>

			to threshold value. This field is only valid when NDFC_RDATA_STA_EN is 1. The threshold value is configured in NDFC_RDATA_STA_TH.
12	R	/	NDFC_RDATA_STA_1 0: The number of bit 0 during current read operation is greater than threshold value. 1: The number of bit 0 during current read operation is less than or equal to threshold value. This field is only valid when NDFC_RDATA_STA_EN is 1. The threshold value is configured in NDFC_RDATA_STA_TH.
11	R	/	NDFC_RB_STATE3 NAND Flash R/B 3 Line State 0: NAND Flash in BUSY State 1: NAND Flash in READY State
10	R	/	NDFC_RB_STATE2 NAND Flash R/B 2 Line State 0: NAND Flash in BUSY State 1: NAND Flash in READY State
9	R	/	NDFC_RB_STATE1 NAND Flash R/B 1 Line State 0: NAND Flash in BUSY State 1: NAND Flash in READY State
8	R	/	NDFC_RB_STATE0 NAND Flash R/B 0 Line State 0: NAND Flash in BUSY State 1: NAND Flash in READY State
7:5	/	/	/
4	R	0	NDFC_STA 0: NDFC FSM in IDLE state 1: NDFC FSM in BUSY state When NDFC_STA is 0, NDFC can accept new command and process command.
3	R	0	NDFC_CMD_FIFO_STATUS 0: Command FIFO not full and can receive new command 1: Full and waiting NDFC to process commands in FIFO Since there is only one 32-bit FIFO for command. When NDFC latches one command, command FIFO is free and can accept another new command.
2	R/W	0	NDFC_DMA_INT_FLAG When it is 1, it means that a pending DMA is completed. It will be clear after writing 1 to this bit or it will be automatically cleared before FSM processing an new command.
1	R/W	0	NDFC_CMD_INT_FLAG When it is 1, it means that NDFC has finished one Normal Command

			Mode or one Batch Command Work Mode. It will be cleared after writing 1 to this bit or it will be automatically cleared before FSM processing an new command.
0	R/W	0	<p>NDFC_RB_B2R</p> <p>When it is 1, it means that NDFC_R/B# signal is transferred from BUSY state to READY state. It will be cleared after writing 1 to this bit.</p>

### 1.4.3. NDFC Interrupt and DMA Enable Register

Offset: 0x08			Register Name: NDFC_INT Default Value: 0x0000_0000
Bit	Read/Write	Default	Description
31:3	/	/	/
2	R/W	0	<p>NDFC_DMA_INT_ENABLE</p> <p>Enable or disable interrupt when a pending DMA is completed.</p>
1	R/W	0	<p>NDFC_CMD_INT_ENABLE</p> <p>Enable or disable interrupt when NDFC has finished the procession of a single command in Normal Command Work Mode or one Batch Command Work Mode.</p> <p>0: Disable 1: Enable</p>
0	R/W	0	<p>NDFC_B2R_INT_ENABLE</p> <p>Enable or disable interrupt when NDFC_RB# signal is transferring from BUSY state to READY state.</p> <p>0: Disable 1: Enable</p>

### 1.4.4. NDFC Timing Control Register

Offset: 0x0C			Register Name: NDFC_TIMING_CTL Default Value: 0x0000_0000
Bit	Read/Write	Default	Description
31:12	/	/	/
11:8	R/W	0	<p>NDFC_READ_PIPE</p> <p>In SDR mode: 0000: Normal 0001: EDO 0010: E-EDO Others : Reserved</p>

			In DDR mode: 0000~1111 is valid(These bits configure the number of clock when data is valid after RE#'s falling edge)
7:6	/	/	/
5:0	R/W	0	NDFC_DC_CTL NDFC Delay Chain Control These bits are only valid in DDR data interface, and configure the relative phase between DQS and DQ[0:7].

### 1.4.5. NDFC Timing Configure Register

Offset: 0x10			Register Name: NDFC_TIMING_CFG Default Value: 0x0000_0095
Bit	Read/Write	Default	Description
31:20	/	/	/
19:18	R/W	0	tWC Write Cycle Time 00: 1*2T 01: 2*2T 10: 3*2T 11: 4*2T
17:16	R/W	0	tCCS Change Column Setup Time 00: 12*2T 01: 20*2T 10: 28*2T 11: 60*2T
15:14	R/W	0	tCLHZ CLE High to Output Hi-z 00: 2*2T 01: 8*2T 10: 16*2T 11: 31*2T
13:12	R/W	0	tCS CE Setup Time 00: 2*2T 01: 8*2T 10: 16*2T 11: 31*2T
11	R/W	0	T_CDQSS DQS Setup Time for data input start 0: 4*2T

			1: 20*2T
10:8	R/W	0	T_CAD Command, Address, Data Delay 000: 2*2T 001: 6*2T 010: 10*2T 011: 14*2T 100: 22*2T 101: 30*2T 110/111: 62*2T
7:6	R/W	0x2	T_RHW RE# high to WE# low cycle number 00: 4*2T 01: 12*2T 10: 20*2T 11: 28*2T
5:4	R/W	0x1	T_WHR WE# high to RE# low cycle number 00: 0*2T 01: 6*2T 10: 14*2T 11: 22*2T
3:2	R/W	0x1	T_ADL Address to data loading cycle number 00: 0*2T 01: 6*2T 10: 14*2T 11: 22*2T
1:0	R/W	0x1	T_WB WE# high to busy cycle number 00: 14*2T 01: 22*2T 10: 30*2T 11: 38*2T

#### 1.4.6. NDFC Address Low Word Register

<b>Offset: 0x14</b>			<b>Register Name: NDFC_ADDR_LOW</b> <b>Default Value: 0x0000_0000</b>
Bit	Read/Write	Default	Description
31:24	R/W	0	ADDR_DATA4 NAND Flash 4 <sup>th</sup> Cycle Address Data

23:16	R/W	0	ADDR_DATA3 NAND Flash 3 <sup>rd</sup> Cycle Address Data
15:8	R/W	0	ADDR_DATA2 NAND Flash 2 <sup>nd</sup> Cycle Address Data
7:0	R/W	0	ADDR_DATA1 NAND Flash 1 <sup>st</sup> Cycle Address Data

### 1.4.7. NDFC Address High Word Register

Offset: 0x18			Register Name: NDFC_ADDR_HIGH Default Value: 0x0000_0000
Bit	Read/Write	Default	Description
31:24	R/W	0	ADDR_DATA8 NAND Flash 8 <sup>th</sup> Cycle Address Data
23:16	R/W	0	ADDR_DATA7 NAND Flash 7 <sup>th</sup> Cycle Address Data
15:8	R/W	0	ADDR_DATA6 NAND Flash 6 <sup>th</sup> Cycle Address Data
7:0	R/W	0	ADDR_DATA5 NAND Flash 5 <sup>th</sup> Cycle Address Data

### 1.4.8. NDFC Data Block Number Register

Offset: 0x1C			Register Name: NDFC_DATA_BLOCK_NUM Default Value: 0x0000_0000
Bit	Read/Write	Default	Description
31:6	/	/	/
4:0	R/W	0	NDFC_DATA_BLOCK_NUM DATA BLOCK Number It is used for batch command procession. 0: no data 1: 1 data blocks 2: 2 data blocks ... 16: 16 data blocks Others: Reserved Notes: 1 data block = 512 or 1024 bytes main field data

### 1.4.9. NDFC Data Counter Register

Offset: 0x20			Register Name: NDFC_CNT Default Value: 0x0000_0000
Bit	Read/Write	Default	Description
31:10	/	/	/
9:0	R/W	0	NDFC_DATA_CNT Transfer Data Byte Counter The length can be set from 1 byte to 1024 bytes. However, 1024 bytes is set when it is zero.

### 1.4.10. NDFC Command IO Register

Offset: 0x24			Register Name: NDFC_CMD Default Value: 0x0000_0000
Bit	Read/Write	Default	Description
31:30	R/W	0	NDFC_CMD_TYPE 00: Common command for normal operation 01: Special command for Flash spare field operation 10: Page command for batch process operation 11: Reserved
29	R/W	0	NDFC_SEND_FOURTH_CMD 0: Don't send third set command 1: Send it on the external memory's bus Notes: It is used for EF-NAND page read.
28	R/W	0	NDFC_SEND_THIRD_CMD 0: Don't send third set command 1: Send it on the external memory's bus Notes: It is used for EF-NAND page read.
27	R/W	0	NDFC_ROW_ADDR_AUTO Row address auto increase for page command 0: Normal operation 1: Row address increasing automatically
26	R/W	0	NDFC_DATA_METHOD Data swap method when the internal RAM and system memory It is only active for common command and special command. 0: No action 1: DMA transfer automatically It only is active when NDFC_RAM_METHOD is 1. If this bit is set to 1, NDFC should setup DRQ to fetching data before output to Flash or NDFC should setup DRQ to sending out to system memory after fetching data from Flash.

			If this bit is set to 0, NDFC output the data in internal RAM or do nothing after fetching data from Flash.
25	R/W	0	NDFC_SEQ User data & BCH check word position. It only is active for Page Command, don't care about this bit for other two commands 0: Interleave Method (on page spare area) 1: Sequence Method (following data block)
24	R/W	0	NDFC_SEND_SECOND_CMD 0: Don't send second set command 1: Send it on the external memory's bus
23	R/W	0	NDFC_WAIT_FLAG 0: NDFC can transfer data regardless of the internal NDFC_RB wire 1: NDFC can transfer data when the internal NDFC_RB wire is READY; otherwise it can't when the internal NDFC_RB wire is BUSY.
22	R/W	0	NDFC_SEND_FIRST_CMD 0: Don't send first set command 1: Send it on the external memory's bus
21	R/W	0	NDFC_DATA_TRANS 0: No data transfer on external memory bus 1: Data transfer and direction is decided by the field NDFC_ACCESS_DIR
20	R/W	0	NDFC_ACCESS_DIR 0: Read NAND Flash 1: Write NAND Flash
19	R/W	0	NDFC_SEND_ADR 0: Don't send ADDRESS 1: Send N cycles ADDRESS, the number N is specified by NDFC_ADR_NUM field
18:16	R/W	0	NDFC_ADR_NUM Address Cycles' Number 000: 1 cycle address field 001: 2 cycles address field 010: 3 cycles address field 011: 4 cycles address field 100: 5 cycles address field 101: 6 cycles address field 110: 7 cycles address field 111: 8 cycles address field
15:8	R/W	0	NDFC_CMD_HIGH_BYTE NDFC Command high byte data If 8-bit command is supported, the high byte should be zero for 16-bit bus width NAND Flash. For 8-bit bus width NAND Flash, high byte command is discarded.
7:0	R/W	0	NDFC_CMD_LOW_BYTE

			NDFC Command low byte data This command will be sent to external Flash by NDFC.
--	--	--	--

#### 1.4.11. NDFC Command Set Register 0

<b>Offset: 0x28</b>			<b>Register Name: NDFC_CMD_SET0</b> <b>Default Value: 0x00E0_0530</b>
Bit	Read/Write	Default	Description
31:24	/	/	/
23:16	R/W	0xE0	NDFC_RANDOM_READ_CMD1 Used for Batch Read Operation
15:8	R/W	0x05	NDFC_RANDOM_READ_CMD0 Used for Batch Read Operation
7:0	R/W	0x30	NDFC_READ_CMD Used for Batch Read Operation

#### 1.4.12. NDFC Command Set Register 1

<b>Offset: 0x2C</b>			<b>Register Name: NDFC_CMD_SET1</b> <b>Default Value: 0x7000_8510</b>
Bit	Read/Write	Default	Description
31:16	R/W	0x70	NDFC_READ_CMD0 Used for EF-NAND Page Read operation
23:16	R/W	0x00	NDFC_READ_CMD1 Used for EF-NAND Page Read operation
15:8	R/W	0x85	NDFC_RANDOM_WRITE_CMD Used for Batch Write Operation
7:0	R/W	0x10	NDFC_PROGRAM_CMD Used for Batch Write Operation

#### 1.4.13. NDFC IO Data Register

<b>Offset: 0x30</b>			<b>Register Name: NDFC_IO_DATA</b> <b>Default Value: 0x0000_0000</b>
Bit	Read/Write	Default	Description
31:0	R/W	0	NDFC_IO_DATA Read/ Write data into internal RAM Access unit is 32-bit.

### 1.4.14. NDFC ECC Control Register

Offset: 0x34			Register Name: NDFC_ECC_CTL Default Value: 0x4a80_0008
Bit	Read/Write	Default	Description
31	/	/	/
30:16	R/W	0x4a80	NDFC_RANDOM_SEED The seed value for randomize engine. It is only active when NDFC_RANDOM_EN is set to '1'.
15:12	R/W	0	NDFC_ECC_MODE 0x0: BCH-16 for one ECC Data Block 0x1: BCH-24 for one ECC Data Block 0x2: BCH-28 for one ECC Data Block 0x3: BCH-32 for one ECC Data Block 0x4: BCH-40 for one ECC Data Block 0x5: BCH-48 for one ECC Data Block 0x6: BCH-56 for one ECC Data Block 0x7: BCH-60 for one ECC Data Block 0x8: BCH-64 for one ECC Data Block Others: Reserved
11	R/W	0	NDFC_RANDOM_SIZE 0: ECC block size 1: Page size
10	R/W	0	NDFC_RANDOM_DIRECTION 0: LSB first 1: MSB first
9	R/W	0	NDFC_RANDOM_EN 0: Disable Data Randomize 1: Enable Data Randomize
8:6	/	/	/
5	R/W	0	NDFC_ECC_BLOCK_SIZE 0: 1024 bytes of one ECC data block 1: 512 bytes of one ECC data block
4	R/W	0	NDFC_ECC_EXCEPTION 0: Normal ECC 1: For ECC, there is an exception. If all data is 0xff or 0x00 for the block. When reading this page, ECC assumes that it is right. For this case, no error information is reported. Notes: It is only active when ECC is ON
3	R/W	0x1	NDFC_ECC_PIPELINE Pipeline function enable or disable for batch command 0: Error correction function no pipeline with next block operation 1: Error correction pipeline

2:1	/	/	/
0	R/W	0	<p>NDFC_ECC_EN</p> <p>0: ECC is OFF</p> <p>1: ECC is ON</p>

#### 1.4.15. NDFC ECC Status Register

Offset: 0x38			Register Name: NDFC_ECC_ST Default Value: 0x0000_0000
Bit	Read/Write	Default	Description
31:16	R	0	<p>NDFC_PAT_FOUND</p> <p>Special pattern (all 0x00 or all 0xff) Found Flag for 16 Data Blocks</p> <p>0: No Found</p> <p>1: Special pattern is found</p> <p>When this field is '1', this means that the special data is found for reading external nand flash. The register of NDFC_PAT_ID would indicate which pattern is found.</p>
15:0	R	0	<p>NDFC_ECC_ERR</p> <p>Error information bit of 16 Data Blocks</p> <p>0: ECC can correct these error bits or there is no error bit</p> <p>1: Error bits number beyond of ECC correction capability and can't correct them</p> <p>Notes: The LSB of this register corresponds the 1st ECC data block. 1 ECC Data Block = 512 or 1024 bytes.</p>

#### 1.4.16. NDFC Enhanced Feature Register

Offset: 0x3C			Register Name: NDFC_EFR Default Value: 0x0000_0000
Bit	Read/Write	Default	Description
31:9	R/W	0	/
8	R/W	0	<p>NDFC_WP_CTRL</p> <p>NAND Flash Write Protect Control Bit</p> <p>0: Write Protect is active</p> <p>1: Write Protect is not active</p> <p>Notes: When this bit is '0', WP signal line is low level and external NAND flash is on protected state.</p>
7	/	/	/
6:0	R/W	0	<p>NDFC_ECC_DEBUG</p> <p>For the purpose of debugging ECC engine, special bits error is inserted before writing external Flash Memory.</p>

			0: No error is inserted (ECC Normal Operation) n: N bits error is inserted
--	--	--	---

#### 1.4.17. NDFC Error Counter Register 0

Offset: 0x40			Register Name: NDFC_ERR_CNT0 Default Value: 0x0000_0000
Bit	Read/Write	Default	Description
[8i+7:8i] (i=0~3)	R	0	ECC_COR_NUM ECC Corrected Bits Number for ECC Data Block[n] (n from 0 to 3) 0: No corrected bits 1: 1 corrected bit 2: 2 corrected bits ... 64: 64 corrected bits Others: Reserved Notes: 1 ECC Data Block = 512 or 1024 bytes

#### 1.4.18. NDFC Error Counter Register 1

Offset: 0x44			Register Name: NDFC_ERR_CNT1 Default Value: 0x0000_0000
Bit	Read/Write	Default	Description
[8i+7:8i] (i=0~3)	R	0	ECC_COR_NUM ECC Corrected Bits Number for ECC Data Block[n] (n from 4 to 7) 0: No corrected bits 1: 1 corrected bit 2: 2 corrected bits ... 64: 64 corrected bits Others: Reserved Notes: 1 ECC Data Block = 512 or 1024 bytes

#### 1.4.19. NDFC Error Counter Register 2

Offset: 0x48			Register Name: NDFC_ERR_CNT2 Default Value: 0x0000_0000
Bit	Read/Write	Default	Description
[8i+7:8i] (i=0~3)	R	0	ECC_COR_NUM ECC Corrected Bits Number for ECC Data Block[n] (n from 8 to 11)

			0: No corrected bits 1: 1 corrected bit 2: 2 corrected bits ... 64: 64 corrected bits Others: Reserved Notes: 1 ECC Data Block = 512 or 1024 bytes
--	--	--	--

### 1.4.20. NDFC Error Counter Register 3

<b>Offset: 0x4C</b>			<b>Register Name: NDFC_ERR_CNT3</b> <b>Default Value: 0x0000_0000</b>
Bit	Read/Write	Default	Description
[8i+7:8i] (i=0~3)	R	0	ECC_COR_NUM ECC Corrected Bits Number for ECC Data Block[n] (n from 12 to 15) 0: No corrected bits 1: 1 corrected bit 2: 2 corrected bits ... 64: 64 corrected bits Others: Reserved Notes: 1 ECC Data Block = 512 or 1024 bytes

### 1.4.21. NDFC User Data Register [n]

<b>Offset: 0x50 + 0x4*n</b>			<b>Register Name: NDFC_USER_DATAn</b> <b>Default Value: 0xffff_ffff</b>
Bit	Read/Write	Default	Description
31:0	R/W	0xffffffff	USER_DATA User Data for ECC Data Block[n] (n from 0 to 15) Notes: 1 ECC Data Block = 512 or 1024 bytes

Notes: n from 0 to 15

### 1.4.22. NDFC EFNAND STATUS Register

<b>Offset: 0x90</b>			<b>Register Name: NDFC_EFNAND_STATUS</b> <b>Default Value: 0x0000_0000</b>
Bit	Read/Write	Default	Description
31:8	/	/	/

7:0	R	0x0	EF_NAND_STATUS The Status Value for EF-NAND Page Read operation
-----	---	-----	--

### 1.4.23. NDFC Spare Area Register

<b>Offset: 0xA0</b>			<b>Register Name: NDFC_SPARE_AREA</b> <b>Default Value: 0x0000_0400</b>
Bit	Read/Write	Default	Description
31:16	/	/	/
15:0	R/W	0x400	NDFC_SPARE_ADR This value indicates the spare area first byte address for NDFC interleave page operation.

### 1.4.24. NDFC Pattern ID Register

<b>Offset: 0xA4</b>			<b>Register Name: NDFC_PAT_ID</b> <b>Default Value: 0x0000_0000</b>
Bit	Read/Write	Default	Description
[2i+1:2i] (i=0~15)	R	0	PAT_ID Special Pattern ID for 16 ECC data block 0: All 0x00 is found 1: All 0xFF is found Others: Reserved

### 1.4.25. NDFC Read Data Status Register

<b>Offset: 0xA8</b>			<b>Register Name: NDFC_RDATA_STA</b> <b>Default Value: 0x0100_0000</b>
Bit	Read/Write	Default	Description
31:25	/	/	/
24	R/W	0x1	NDFC_RDATA_STA_EN 0: Disable the counting number of bit 1 and bit 0 during current read operation. 1: Enable the counting number of bit 1 and bit 0 during current read operation. The number of bit 1 and bit 0 during current read operation can be used to check whether a page is blank or bad.
23:18	/	/	/
17:0	R/W	0	NDFC_RDATA_STA_TH

			The threshold value to generate data status. If the number of bit 1 during current read operation is less than or equal to threshold value, the bit 13 of NDFC_ST register will be set. If the number of bit 0 during current read operation is less than or equal to threshold value, the bit 12 of NDFC_ST register will be set.
--	--	--	--

#### 1.4.26. NDFC Read Data Status Register 0

<b>Offset: 0xAC</b>			<b>Register Name: NDFC_RDATA_STA_0</b> <b>Default Value: 0x0000_0000</b>
Bit	Read/Write	Default	Description
31:0	R	0	BIT_CNT_1 The number of input bit 1 during current command. It will be cleared automatically when the next command is executed.

#### 1.4.27. NDFC Read Data Status Register 1

<b>Offset: 0xB0</b>			<b>Register Name: NDFC_RDATA_STA_1</b> <b>Default Value: 0x0000_0000</b>
Bit	Read/Write	Default	Description
31:0	R	0	BIT_CNT_0 The number of input bit 0 during current command. It will be cleared automatically when the next command is executed.

#### 1.4.28. NDFC MBUS DMA Address Register

<b>Offset: 0xC0</b>			<b>Register Name: NDFC_MDMA_ADDR</b> <b>Default Value: 0x0000_0000</b>
Bit	Read/Write	Default	Description
31:0	R/W	0	MDMA_ADDR MBUS DMA address

#### 1.4.29. NDFC MBUS DMA Byte Counter Register

<b>Offset: 0xC4</b>			<b>Register Name: NDFC_MDMA_CNT</b> <b>Default Value: 0x0000_0000</b>
Bit	Read/Write	Default	Description
14:0	R/W	0	MDMA_CNT

### 1.5. NDFC Operation Diagram




Figure 12. Page Read Command Diagram




Figure 13. Page Program Diagram




Figure 14. EF-NAND Page Read Diagram




Figure 15. Interleave Page Read Diagram